

Leak test to control leak detectors

Fuite test pour le contrôle des détecteurs

Type FT-CONT

FT-CONT-1216-E-F



EFFICIENT & EASY

Calibrated leak

*Approach your leak detector from the bottle and open the CAP.
Check that your detector reacts in the presence of this simulation of a leak on a refrigeration or air conditioning installation.*

*If air temperature is low, warm the bottle in your hand 1 minute.
Close after use.*

*Temperature range +10 to 30°C.
Leak rate varies according to ambient temperature*

Use

*Keep in vertical position and place the leak detector on the top of the cover.
The leak does not require special or particular care.
Store in vertical position*

EFFICACE & SIMPLE

Fuite Test

Approcher votre détecteur de fuites de la fiole et ouvrez le bouchon.
Vérifier que votre détecteur réagit en présence de cette simulation d'une fuite sur un installation de réfrigération ou de climatisation.
Si la température ambiante est trop basse, réchauffez la bouteille dans la main 1 minute.
Refermer après usage.
Température d'utilisation de +10 à 30°C.
La valeur de la fuite évolue légèrement avec la température ambiante.

Utilisation

Maintenir en position verticale.

Soucieux d'améliorer la qualité de ses produits Galaxair se réserve le droit de modifications sans préavis